



THUASNE

Osteomed Acute



Osteomed Acute Semi-Rigid Back Panel

Provides additional lumbar and thoracic support.

Instructions for Use

Follow Osteomed Acute Instructions for Use for fitting and adjustment of the entire brace.



1. Align back panel inside the posterior section as shown.



2. Press back panel to securely attach Velcro.

3. The semi rigid panel can be removed for heat molding and other modification.