



THUASNE

Condylar Pads


How to add condylar pads

1. Remove the plastic film cover from the adhesive side of the condylar pad.
2. Affix the condylar pad (sticky side down) to the interior side of the brace at the knee center.
3. Press firmly to secure the condylar pad to the brace.
4. Repeat on the other condyle side if desired.

Removable Shells

If required you may remove the exterior thigh or tibia shell and trim the shape.

1. Remove the shell from the brace.
2. Trim with scissors. You can use sand paper to smooth the edges if required.
3. Re-apply the shell with the attached hook.
4. When re-attaching the shell, make sure the cut outs match carefully with the black laces.




Action Reliever




Extension Stops

0° Stop
(Installed)




10° Stop



How to Insert an Extension Stop

1. Remove the upright from the brace.
 - A. Remove the Allen screw on the hinge by using an Allen Wrench, size 5/64. Take out the zero-degree extension stop that comes standard on each brace.
 - B. Insert the 10-degree extension stop. Make sure the hole in the hinge and the hole in the extension stop are aligned. Replace the Allen screw.
2. Extend the hinge to confirm that the stop is working properly.
3. Re-insert the hinge back into the sleeve where it was removed on the side of the brace. It is snug so be careful as you maneuver it back into place.




Flexion Stops

20° Stop



40° Stop



How to Insert a Flexion stop

1. Remove the upright from the brace.
 - a. Pick the degree of flexion you require
 - b. Insert the desired flexion stop in the back of the hinge. Make sure the hole in the hinge and the hole in the extension stop are aligned. Tighten with provided Allen screw.
2. Flex the hinge to confirm that the stop is working properly.
3. Re-insert the hinge back into the sleeve where it was removed on the side of the brace. It may be a little snug, so be patient as you maneuver it back into place.